
universal and frame fixings

Vorpa **HZ - HB**

Universal ligth fixing for plasterboard



products group




quick and easy installation

installation sequence

suitable for wood, self-tapping and chipboard screws


Suggestion for use

- · respect the installation data
- the installation torque should be limited when using a battery operated screwdriver
- no suitable for tiled plasterboard



product code and technical data

Code	Description	L _t mm	T _{fix} mm	Ø _v xL _v mm
2523s	HZ 29 no accessories	29	13	4,5x25
2523	HZV 29 TC with cylinder head screw	29	13	4,5x25
2755	HZV 29 TSP with chipboard screw	29	13	4,5x25
521	HB 30 with countersunk head screw	30	12	3x25



 L_v = Screw length

Screw length calculation: $L_v > L_t + T_{fix}$

ATTENTION: An appropriate safety factor \geq 5 should be applied on these values

HZ - HB			
	HZ	HB	
Pull out values in daN			1 daN _~ 1 kg
Plasterboard 10mm	40	20	
Plasterboard > 12,5 mm	50	30	
Plasterboard \geq 25 mm	67	45	